

# The Ultimate Guide to BULLDOZER PARTS

## EVERYTHING YOU NEED TO KNOW


When it comes to construction equipment, bulldozers might be the most important piece of machinery.

Gaining a better understanding of bulldozer parts can help operators and mechanics follow best maintenance practices, troubleshoot problems, and operate the machinery at its highest level of performance.

## BULLDOZER PARTS AND FUNCTIONS

### 1 THE BULLDOZER UNDERCARRIAGE

The bulldozer undercarriage is the supporting foundation of the entire machine. Including the tracks, rollers, idlers, and sprockets, all parts work together to provide stability when operating across various types of land.




### 2 THE BULLDOZER BLADE

The blade is what makes the bulldozer so effective in moving heavy material. Depending on the task at hand, three different blade types are used: straight blade, angle blade, and universal blade.




### 3 THE BULLDOZER RIPPER

The ripper breaks up hard ground, rocks, and other materials that cannot be moved by the blades.



### 4 THE BULLDOZER HYDRAULICS

As the powerhouse behind many of the bulldozer's functions, the hydraulics provide the force needed to move and control different aspects of the blade and ripper.



### 5 THE BULLDOZER ENGINE AND TRANSMISSION

If the bulldozer undercarriage is considered the foundation, the bulldozer engine and transmission are the heart and soul. They provide the power and movement needed to complete heavy-duty tasks.

### 6 OTHER ESSENTIAL BULLDOZER PARTS

While there are five major components to a bulldozer, additional parts contribute to the bulldozer's overall effectiveness.

**COOLING SYSTEM, ELECTRICAL SYSTEM, OPERATOR CAB AND CONTROLS, FINAL DRIVES**



## BECOME A BULLDOZER OPERATOR

Start your career in the construction industry and become a certified bulldozer operator through Heavy Equipment College's certification program.



Heavy Equipment Colleges of America

[HeavyEquipmentCollege.edu](http://HeavyEquipmentCollege.edu)

(888) 519-3928